


# Guitar Controller Setup and Usage Instructions

Congratulations on your purchase of a GUITAR THUNDER Guitar Controller! Please read the following instructions carefully before attempting to use the controller.

## INTRODUCTION



\*The actual style of the guitar controller may be different from the example shown above.

- START button : Pause
- SELECT button : Activate Star Power
- GREEN button : Activate the Green note / Confirm
- RED button : Activate the Red note / Cancel
- YELLOW button : Activate the Yellow note
- BLUE button : Activate the Blue note
- ORANGE button : Activate the Orange note
- STRUM BAR : Move the Strum Bar up or down to activate the color buttons and to navigate the menu
- Whammy Bar : Press the bar down to alter the sound of the song
- Tilt Sensor : Located inside the casing at the base of the neck. It is used to activate the Star Power. To activate, tilt the neck of the controller up or down.